



- Thank you for purchasing our product. Before installing/operating the product, read the instructions carefully and retain them for future reference.

⚠ Attention!

- For installation, follow the steps described. Any damage caused by wrong installation shall be imputed to the users.
- To avoid a short circuit from occurring do not pull or modify the wires during installation.
- Do not disassemble or change any parts. Opening and disassembling this unit will void any warranty.
- Maintenance and repairs should be executed by our professionals only.

Symbol description:

NOTE

⚠ Some procedures must be followed to avoid damages to the product.

⚠ **WARNING!** Certain procedure must be followed to avoid damages to yourself, to the vehicle or to others.



Flash



Light on

















Hold the
Button
1 second




Hold the
Button
3 seconds


1-1 Accessories

1 LCD Meter X1 	2 Active speed sensor X1 	3 M8 / S type speed sensor bracket X 1 	4 M10 / S type speed sensor bracket X 1 
5 M5x5xP0.8 Hexagon screw X 2 	6 2.5 mm Allen key X 1 	7 Meter bracket X1 	8 M5 washer X2 
9 M5x16LxP0.8 Allen screw X2 	10 Rubber strip X1 	11 Handlebar clamp X1 	12 M8x20LxP1.25 Allen screw X1 
13 M8 washer X1 	14 M8xP1.25 nut X1 		

1-2 Optional accessories


1 L type speed sensor bracket  BI003S01

2 Wiring Installation Instructions



NOTE When connecting the power wire, carefully follow the instructions. If the red & brown wires are connected in parallel, the meter won't work properly.

3 Installation instructions



Follow the steps below during installation.

1. Handlebar
2. Rubber strip (Accessory 10)

CAUTION! Refer to the list below for use of the rubber strip


Handle bar SIZE	Use Rubber strip
7/8"(22.2 mm)	NO
1"(25.4 mm)	YES

3. Handlebar clamp (Accessory 11)
4. Meter bracket (Accessory 7)
5. M8x20LxP1.25 Allen screw (Accessory 12)
6. M8 washer (Accessory 13)
7. M8xP1.25 nut (Accessory 14)
8. LCD Meter (Accessory 1)
9. M5 washer X2 (Accessory 8)
10. M5x16LxP0.8 Allen screw X2 (Accessory 9)

MOTO / SCOOTER S type speed sensor bracket instruction




Install the S type sensor bracket .



Install the speed sensor on the bracket .



Adjust the sensor bracket position to make sure that the sensor faces the magnet to prevent bad speed signal or no signal.



Adjust the distance between sensor and magnet. We suggest you make sure the distance is under **1 mm** for an optimal speed signal.


MOTO / SCOOTER L type speed sensor bracket instruction




Install the L bracket and the anti-slip rubber on the front fork and adjust it to the proper height and angle.



Install the speed sensor into the proper hole on the bracket.



Use the zip tie to fix the bracket on the front fork. Make sure the disc screw can pass the hole on the bracket for you to install the sensor into the same hole to catch the speed signal.



Adjust the distance between the sensor and screw to get the best speed signal. Make sure the distance is under 1 mm to get the best signal.

PS.



The active speed sensor needs to be facing a metal surface to detect the speed.

EX. 1 The disc screw.

EX. 2 The disc to detect the disc gap. (Make sure the distances between the gaps are the same in advance to avoid improper speed signal.)


EX. 3 The sprocket to detect the disc gap. (Make sure the distances between the gaps are the same in advance to avoid improper speed signal.)

EX. 4 Rear disc - detect the gap between the disc.

We suggest you obtain the speed from the disc screws. The more sensor points are, the better the speed accuracy is. The maximum sensor points the speed sensor could detect is 40 points per turn.


⚠ **After installation, use your hand to turn the tire to see if everything is ok. The LED on the active speed sensor will light up once the signal is detected.**

EX. 1



The hexagon socket disc screw
The best detection area: The edge of the hexagon socket screw.


⚠ Don't pick-up the signal from the middle hole of the hexagon socket screw to avoid wrong signal.



The hexagon screw
The best detection area: The middle of the screws.

⚠ Some hexagon screw centers have a small hole in this case, we suggest you to obtain the signal from the edge of the screw like the hexagon socket screw.


EX. 2,4



The disc
The best detection area: Detect the speed signal from the gaps of the disc.

⚠ Note that there are discs with the gaps in different locations, so this method may not work.


EX. 3




The sprocket
The best detection area: Detect the speed signal from the gaps of the sprocket.

⚠ Note that there are sprockets with the gaps in different locations, so this method may not work.

3-1 Meter Size



3-2 Basic Function Instructions





3-3 Specifications

●Speedometer	Display range : 0 ~ 160 km/h (MPH) Display unit : 20 km/h (MPH) (Large grid), 10km/h (MPH) (Small grid)	○Low Fuel warning	Setting range : 0~30%, when setting value is reached or below, warning light will illuminate. Setting unit : 10%
○Speed warning setting	Display range : 30~160 km/h (19~100 MPH), when setting value is reached or above, warning light will illuminate. Display unit : 1 km/h (MPH)	●Voltmeter	Display range : DC 8.0 ~ 18.0 V Display unit : DC 0.1 V
○Max. speed record	Display range : 0~160 km/h (MPH), can return to zero manually Display unit : 1 km/h (MPH)	○Low voltage warning	Setting range : DC 8.0~13.0 V, when setting value is reached or below, warning light will illuminate. Setting unit : 0.1 V
○Odometer	Setting range : 0 ~ 99,999 km (mile) Setting unit : 1 km (mile)	●Backlight color	Setting range : white, red, yellow, green, blue, light blue, purple Loop switch
○Trip meter	Display range : 0.0~9,999.9 km (mile), can return to zero manually Display unit : 0.1 km (mile)	●Unit	Speed unit : km, mile
○Circumference	Setting range : 300~2,500 mm Setting unit : 1 mm	●Operating voltage	DC 12V
○Sensitive point	Setting range : 1~20 P Setting unit : 1 P	●Operating temperature	-10~ +60 °C
●Fuel meter	Display range : 10 levels (100%) Display unit : 1 levels (10%)	○Storage temperature	-20~ +80 °C
○Fuel Gauge Resistance(Ω)	Setting range : 100 Ω, 250 Ω, 270 Ω, 390 Ω, 510 Ω, 1200 Ω, Sw, Custom(learning mode), OFF	●Specification	JIS D 0203(S2)
		●Meter Size	D 48 mm
		●Meter Weight	± 90 g
		●Indicator	Speed warning (Red)


NOTE Design and specifications are subject to change without notice.

4 Main Menu Switching Description



5 Setting Screen Switching Description

- Press the **button** for 3 seconds in the main screen(ODO) to switch to the setting screen.
 - Press the **button** to select
- ①Unit(Speed) ②Backlight(Color) ③Tire circumference, Sensing point ④Speeding warning ⑤Voltage ⑥Fuel resistance, Low Fuel warning ⑦Internal and External ODO
- NOTE** During setting, if no button is not pressed for 30 seconds, it will automatically return to the startup screen.



5-1 Unit (Speed) Setting



- In the unit screen, press the **button for 3 seconds** to enter the speed unit setting.



- Example : To set speed unit in km.**
- Press the **button** to choose the setting options.

⚠ Now the setting value is flashing.

NOTE Setting range : km, mile.
Default value : mile.



- EX : Set speed unit from mile to km.
- Press the **button for 3 seconds** to go back to the unit screen.



- The unit screen.

5-2 Backlight (Color) Setting



- In the backlight screen, press the **button for 3 seconds** to enter the backlight color setting.



- Example : To set backlight color to yellow.**
- Press the **button** to choose the color.

⚠ Now the setting value is flashing.

NOTE Setting range : white, red, yellow, green, blue, light blue, purple
Default value : White.

NOTE The backlight color will change immediately after you set the value.



- EX : Set backlight color from white to yellow.
- Press the **button for 3 seconds** to go back to the backlight screen.



- The backlight screen.

5-3 Tire Circumference and sensing point setting



- In the tire circumference and sensing point screen, press the **button for 3 seconds** to enter the tire circumference and sensing point setting.

⚠ **CAUTION!**

- Measure the tire circumference (The tire you will install the sensor on) to confirm the sensor point value.
- The speed displayed on the meter will be affected by the setting, make sure the setting number is correct before you enter the setting.


⚠ Reset this setting value if you change to a different tire size.



- Example : If the tire circumference is 1,300 mm.**
- Press the **button for 3 seconds** to move to the digit you want to set.

⚠ Now the setting value is flashing.

NOTE Setting range : 300~2,500 mm.
Default value : 1,000 mm.



- Press the **button** to choose the setting number.



- EX : Set the tire circumference value from 1,000 mm to 1,300 mm.
- Press the **button for 3 seconds** to enter the sensor point setting.



- Example : To set the sensor point value to 06 P .**

- Press the **button for 3 seconds** to move to the digit you want to set.

⚠ Now the setting value is flashing.

NOTE Setting range : 01 P~20 P.
Default value : 01 P.



- Press the **button** to choose the setting number.



- EX : Set the sensor point value from 01 P to 06 P.
- Press the **button for 3 seconds** to go back to the tire circumference and sensing point screen.



- The tire circumference and sensing point screen.

5-4 Speed Warning Setting



- In the speeding warning screen, press the **button for 3 seconds** to enter the speeding warning setting.



- **Example : To set speeding warning value to 51 MPH.**
- Press the **button for 3 seconds** to move to the digit you want to set.

⚠ Now the setting value is flashing.

NOTE Setting range : 30~160 km/h
(19~100 MPH).
Default value : 60 km/h (38 MPH).



- Press the **button** to choose the setting number.



- EX : Set speed warning value from 38 MPH to 51 MPH.
- Press the **button for 3 seconds** to go back to the speed warning screen.



- The speeding warning screen.

5-5 Voltage Setting



- In the voltage screen, press the **button for 3 seconds** to enter the voltage setting.



- **Example : To set voltage function to ON .**
- Press the **button** to choose the setting options.

⚠ Now the setting value will blink.

NOTE Settings range : ON, OFF.
Default value : ON.



- EX : Set voltage function to ON .
- Press the **button for 3 seconds** to enter the low voltage warning setting.



- **Example : To set low voltage warning value to DC 11.0 V.**
- Press the **button for 3 seconds** to move to the digit you want to set.

⚠ Now the setting value is flashing.

NOTE Setting range : DC 8.0~13.0 V.
Default value : DC 11.5 V.



- Press the **button** to choose the setting number.



- EX : Set low voltage warning value from DC 11.5 V to DC 11.0 V.
- Press the **button for 3 seconds** to go back to the voltage warning screen.



- The voltage screen.

5-6-1 Fuel Setting (Fuel Gauge Resistance (Ω) / Low Fuel Warning)



- In the fuel screen, press the **button for 3 seconds** to enter the fuel gauge resistance setting.



- **Example** : If the vehicle is a **YAMAHA T-MAX 530**, its resistance is **100 Ω** according to the service manual.
- Press the **button** to choose the setting number.

⚠ Now the setting value will blink.

NOTE Settings range : 100 Ω , 250 Ω , 270 Ω , 390 Ω , 510 Ω , 1200 Ω , SW, Custom, OFF.
Default value : 100 Ω .



- EX : Set fuel gauge resistance value to 100 Ω .
- Press the **button for 3 seconds** to enter the low fuel warning setting.

NOTE If the setting is Custom, it will enter the 5-6-2 (auto) and 5-6-3 (manual) operation setting.



- **Example** : To set low fuel warning value to **30%**.
- Press the **button** to choose the setting number.

⚠ Now the setting value is flashing.

NOTE Setting range : 0~30%.
Default value : 10%.



- EX : Set low fuel warning value from 10% to 30%.
- Press the **button for 3 seconds** to go back to the fuel screen.



- The fuel screen.



5-6-2 Fuel Gauge Resistance Setting (Auto Detection)



- Press the **button for 3 seconds** to enter the fuel gauge resistance setting (auto detection).

⚠ **CAUTION!**

- Before detection, ensure that your current fuel level is in the lowest position that you would like to have.
- Stop the vehicle for a few seconds to allow the fuel surface to become steady, then start the detection of the resistance.



P.S.  Try it!

- If the fuel surface sensor floats in the lowest position then press the **button**, it will detect the resistance around 90 Ω .

The lowest position ▶



- EX : Auto Detection the lowest fuel level resistance value is 90 Ω .
- Hold and press the **button 5 times** to enter the highest fuel level resistance auto detection screen.




P.S.



The highest position ▶

- If the fuel surface sensor floats in the highest position then press the **button**, it will detect the resistance around 10 Ω .



- EX : Auto Detection the highest fuel level resistance value is 10 Ω .
- Hold and press the **button 5 times** to enter the low fuel warning setting.



5-6-3 Fuel Gauge Resistance Setting (Manual)



- In the fuel gauge resistance setting(auto detection), press the **button for 3 seconds** to enter the fuel gauge resistance setting (manual).



- **Example : To set the lowest fuel level resistance value as 90 Ω .**
- Press the **button for 3 seconds** to move to the digit you want to set.

⚠ Now the setting value is flashing.



- Press the **button** to choose the setting number.



- **EX : Set the lowest fuel level resistance value from 80 Ω to 90 Ω .**
- Hold and press the **button twice** to enter the highest fuel level resistance setting.



- **Example : To set the highest fuel level resistance value as 10 Ω .**
- Press the **button for 3 seconds** to move to the digit you want to set.

⚠ Now the setting value is flashing.



- Press the **button** to choose the setting number.



- **EX : Set the highest fuel level resistance value to 10 Ω .**
- Press the **button for 3 seconds** to enter the low fuel warning setting.



5-7 Internal and External ODO Setting

Internal ODO



- In the internal and external ODO screen, press the **button for 3 seconds** to enter the internal and external ODO setting.



- Press the **button for 3 seconds** to enter the internal ODO screen.



- The internal ODO screen.

⚠ User unable to adjust or clear internal ODO.

NOTE Display range : 0 ~ 99,999 km (mile).



External ODO



- In the internal and external ODO screen, press the **button for 3 seconds** to enter the internal and external ODO setting.



- Press the **button for 3 seconds** to enter the external ODO setting.



- **Example : To set external total distance value to 12,500 km.**
- Press the **button for 3 seconds** to move to the digit you want to set.

⚠ Now the setting value is flashing.

NOTE Cursor's order : one hundred thousand→ten thousands→thousand→hundred→ten→digit.

NOTE Setting range : 0~99,999 km (mile).



- Press the **button** to choose the setting number.



- **EX : Set external total distance value from 00,000 km to 12,500 km.**
- Press the **button for 3 seconds** to go back to the internal and external ODO screen.



- The internal and external ODO screen.

6 Troubleshooting

The following situations do not indicate malfunctions of the product. Check the following before taking it in for repair.

Trouble	Check item	Trouble	Check item
<p>The meter doesn't work when the power is on.</p> <p>The meter shows wrong information.</p> <p>Speed meter doesn't appear or appears incorrectly.</p>	<ul style="list-style-type: none"> ●The power isn't supplied to the meter. →Make sure the wiring is connected. The wiring and fuse are not broken. →The battery is too old to supply needed power (DC 12 V). ●Check the voltage of your battery, and make sure the voltage is over DC 12 V. ●May be poor connection of the speed sensor. →Check if the speed sensor is connected correctly. ●Check the setting. →Refer to the manual 5-3 Tire Circumference and sensing point setting. 	<p>Fuel meter doesn't display or display error.</p> <p>The meter indicator didn't display.</p>	<ul style="list-style-type: none"> ●Check your fuel tank. ●May be poor connection of the harness. →Make sure the wires are connected correctly. ●Check the setting. →Check the settings menu if the fuel settings are correct. ●Check the setting. →Refer to the manual 5-4 Speeding Warning Setting.

※ If the problems still cannot be solved, contact our technical department for assistance.