

Arctic Cat® Snowmobile

Installation Instructions - Accessory Kit

Vented Hood Panel Kits (p/n 5639-862, 5639-863, 5639-864, 5639-991, 6639-599)



■ **NOTE:** Read these Installation Instructions thoroughly before beginning the installation process. Retain these Installation Instructions for future reference.

Kit includes:

p/n	QTY	DESCRIPTION
5706-292	1	Right-Side Panel w/Screen (Black)
5706-293	1	Left-Side Panel w/Screen (Black)
5706-294	1	Right-Side Panel w/Screen (PC Green)
5706-295	1	Left-Side Panel w/Screen (PC Green)
5706-296	1	Right-Side Panel w/Screen (Orange)
5706-297	1	Left-Side Panel w/Screen (Orange)
5706-376	1	Right-Side Panel w/Screen (White)
5706-377	1	Left-Side Panel w/Screen (White)
5706-980	1	Right-Side Panel w/Screen (TA Green)
5706-981	1	Left-Side Panel w/Screen (TA Green)
1653-725	1	Instructions

■ **NOTE:** These vented kits are recommended for competition use only.

■ **NOTE:** Replacement screens may be ordered. The entire panel does not need to be replaced if a screen gets cut.

Right- and Left-Side Hood Screens (Pair) (p/n 5639-948)

Right-Side Hood Screen (p/n 6606-468)

Left-Side Hood Screen (p/n 6606-469)

■ **NOTE:** Refer to the appropriate Arctic Cat Snowmobile Service Manual for more detailed instructions.

To remove the access panels and hood, use the following procedure:

1. Remove the hairpin clip from the pin located at the front of the access panel. Move the panel up and off the pin; then swing the panel all the way out and unhinge the panel from the lower console.

2. Remove the two torx-head screws securing the hood; then remove the two torx-head screws from the top-side of the hood securing the hood to the upper console.

■ **NOTE:** On the turbo models, remove the two torx-head screws from under the nosepiece of the hood.

3. Locate the hood harness connector and unplug the connector; then move the hood slightly forward and remove the hood.

■ **NOTE:** On the turbo models, first unhook the rubber straps securing the air filter housing to the intake plenum of the hood; then move the hood slightly forward and remove the hood.

4. Remove the two machine screws securing the rear portion of the hood panels (located under the hood panels); then unhinge the hood panels from the air intake plenum and swing them all the way out and unhinge from the front of the intake plenum.
5. Install new Hood Panels w/Screens and secure using existing machine screws.
6. Install hood and secure using existing machine screws. Tighten securely.