

DEEP CUT POINT COVER

Part #: 03-573 & 03-574

Thank you for purchasing this Arlen Ness product. We believe that our products are the very best available and are engineered to provide a lifetime of use. Basic hand tools and a service manual for your year and model motorcycle are all you need to complete this installation.

Parts:

1- Deep Cut point cover
1- 8-32x3/8 flathead allen (chrome)

1- Point cover mounting plate
5- 8-32x3/8 flathead allen



Remove OEM point cover.

Using five 8-32x3/8 flathead allens attach point cover mounting plate to the engine.

Using one 8-32x3/8 chrome flathead allen attach Deep Cut cover to mounting plate.