



311 #1 Industrial Way - Fallbrook, CA 92028 - USA
Phone: (760) 731-1200 Fax: (760) 731-1284
E-mail: tech@baronscustom.com
Website: www.baronscustom.com

Baron Fiberglass Fenders

Hints, tips and precautions on installation and use of Baron Fiberglass Fenders

- Pre-fit all fenders **BEFORE** you paint them.
- Fenders can be trimmed/cut with a cutoff tool or dremel.
- Check clearance on lowered rear suspensions with the rear fully collapsed.
- Check front fender for corner clearance, forward control clearance, tool bag clearance.
- Check rear caliper for clearance (rear caliper can be relocated on some models).
- Check tire clearance.
- Are you frenching-in lights or license? Check the clearance.
- Drill any holes you need for seat mounting, pillion brackets, luggage mounting, light mounting, fender trim, rear racks, license mounting, etc. **prior** to painting.
- Sand gel coat with 320 grit and prime.
- Finish sand primer with 400 wet/dry paper and apply base coat.

Pre mount fender before you paint!