



**BIG BIKE PARTS**

# INSTALLATION INSTRUCTIONS

## CRUISER FOOTREST BOARDS

Part # 21-330, #21-330C, #21-351, #21-351B, 21-553B

Copyright© 2000 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

TOOLS REQUIRED: 8MM ALLEN WRENCH  
14MM SOCKET & WRENCH

1. THIS PART IS SUPPLIED WITH TWO (2) DIFFERENT SIZE BOLTS.
2. USE BOLT SIZE M10 – 1.25 X 65 WHEN ATTACHING THE FOOTREST BOARD ONTO THE FOLLOWING PARTS:  
#21-301 1" UNIVERSAL CLAMP  
#21-302 1" CLAMP (VALKYRIE INTERSTATE)  
#21-303 1 1/4" UNIVERSAL CLAMP  
#21-351 PASSENGER PEG RELOCATOR  
#21-352 DRIVER PEG RELOCATOR  
#21-552 PASSENGER PEG RELOCATOR  
#21-553 PASSENGER PEG RELOCATOR
3. USE BOLT SIZE M10 – 1.25 X 75 WITH LOCK NUT WHEN ATTACHING THE FOOTREST BOARD ONTO THE FOLLOWING PARTS:  
#21-310 STRAIGHT OFFSET EXTENSION  
#21-312 STEPPED OFFSET EXTENSION

**NOTE:** WE RECOMMEND USING "LOCTITE" ON THE THREADS OF THE BOLTS THAT DO NOT UTILIZE LOCK NUTS.



**BIG BIKE PARTS**

# INSTALLATION INSTRUCTIONS

## CRUISER FOOTREST BOARDS

Part # 21-330, #21-330C, 21-351, #21-351B, 21-553B

Copyright© 2000 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

TOOLS REQUIRED: 8MM ALLEN WRENCH  
14MM SOCKET & WRENCH

1. THIS PART IS SUPPLIED WITH TWO (2) DIFFERENT SIZE BOLTS.
2. USE BOLT SIZE M10 – 1.25 X 65 WHEN ATTACHING THE FOOTREST BOARD ONTO THE FOLLOWING PARTS:  
#21-301 1" UNIVERSAL CLAMP  
#21-302 1" CLAMP (VALKYRIE INTERSTATE)  
#21-303 1 1/4" UNIVERSAL CLAMP  
#21-351 PASSENGER PEG RELOCATOR  
#21-352 DRIVER PEG RELOCATOR  
#21-552 PASSENGER PEG RELOCATOR  
#21-553 PASSENGER PEG RELOCATOR
3. USE BOLT SIZE M10 – 1.25 X 75 WITH LOCK NUT WHEN ATTACHING THE FOOTREST BOARD ONTO THE FOLLOWING PARTS:  
#21-310 STRAIGHT OFFSET EXTENSION  
#21-312 STEPPED OFFSET EXTENSION

**NOTE:** WE RECOMMEND USING "LOCTITE" ON THE THREADS OF THE BOLTS THAT DO NOT UTILIZE LOCK NUTS.