

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

Copyright© 2004 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

REPLACEMENT
FLOORBOARDS
PART NO. 21-554

FOR HONDA
VTX 1300 RETRO
VTX 1800 RETRO

TOOLS NEEDED: NEEDLE NOSE PLIERS

1. USING A NEEDLE NOSE PLIERS, REMOVE THE CLIP ON THE PIN HOLDING THE OEM BOARD ON.
2. TAKE OUT THE PIN CAREFULLY NOTING HOW THE SPRING FITS IN.
3. INSTALL THE NEW BOARD RE-USING THE SPRING, PIN AND CLIP.