BIG BIKE PARTS

Copyright 2016 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

INSTALLATION INSTRUCTIONS

PART NO. 30-106

GADGET BAR AND MOUNT

UNIVERSAL FOR 7/8" AND 1" ROUND HANDLEBARS

6/29/2016

TOOLS NEEDED: 2MM ALLEN WRENCH 4MM ALLEN WRENCH

10MM WRENCH

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

ESTIMATED INSTALLATION TIME: 5 TO 10 MIN.

INSTALLATION:

- 1. REMOVE THE TWO RUBBER STRIPS FROM THE HARDWARE PACKAGE.
- 2. THE THICKER STRIP IS USED WHEN INSTALLING ON 7/8" DIAMETER HANDLEBARS AND THE THIN STRIP IS USED FOR 1" DIAMETER HANDLEBARS.
- 3. WRAP THE CORRECT RUBBER STRIP AROUND THE HANDLEBAR AS SHOWN IN FIG. 1 BELOW.
- 4. ASSEMBLE THE CLAMPS AND RECEIVER AS SHOWN IN FIG. 1 USING THE TWO M6 SCREWS AND M6 NUTS.
- 5. ADJUST THE POSITION AS NEEDED AND USING A 4MM ALLEN WRENCH AND A 10MM WRENCH TIGHTEN THE SCREWS.
- 6. INSERT THE GADGET BAR INTO THE RECEIVER. SEE FIG. 2.
- 7. INSTALL THE M3 SCREW AS SHOWN IN FIG. 3.
- 8. ROTATE THE HANDLEBAR TO MAKE SURE THAT THE GADGET BAR DOES NOT HIT THE GAS TANK OR CONSOLE.

