

# **BIG BIKE PARTS®**

LOWER AIR VENTS  
PART NO. 52-552

# INSTALLATION INSTRUCTIONS

FOR GOLDWING  
1988-2000

Copyright© 2000 by Big Bike Parts, Inc.™ No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

TOOLS REQUIRED: (2) FLAT BLADE SCREWDRIVERS

1. TO REMOVE THE EXISTING (OEM) AIR VENT, USE THE SCREWDRIVERS TO PUSH UP ON THE (2) KEEPER TABS (LOCATED ON THE INSIDE LOWER FLANGE). THEN USE A SCREWDRIVER TO PRY BEHIND THE EDGE OF THE VENT.
2. INSTALL NEW VENTS BY PUSHING THEM INTO PLACE UNTIL FLUSH WITH PANEL.