

Copyright© 2012 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts Inc.

REVISED 11/6/14

UNIVERSAL INSTALLATION INSTRUCTIONS

TOOLS NEEDED: VARIES, 1-1/8" DRILL BIT OR HOLE SAW

INSTALLATION:

1. SEPARATE THE 3-PIN WHITE PLUG FROM THE WIRES ON THE HARNESS PROVIDED. CUT THE WIRES CLOSE TO THE PLUG.
2. MOUNT THE USB SOCKET IN THE PREFERRED LOCATION. IT REQUIRES A 1-1/8" HOLE. UNSCREW THE NUT FROM THE USB SOCKET, INSERT THE USB SOCKET INTO THE HOLE, THREAD NUT ONTO SOCKET AND TIGHTEN.
3. CONNECT THE WIRE FROM STEP 1 TO THE BULLET CONNECTORS ON THE USB SOCKET. CONNECT THE BLACK WIRE TO BLACK AND RED WIRE TO RED.
4. USING THE SPLICE CONNECTORS PROVIDED CONNECT THE RED WIRE TO THE POSITIVE AND BLACK WIRES TO THE GROUND.

GL1800 INSTALLATION INSTRUCTIONS

TOOLS NEEDED: SMALL FLATHEAD SCREWDRIVER, 1-1/8" DRILL BIT OR HOLE SAW

INSTALLATION:

NOTE: THE 5 AMP ACCESSORY FUSE MAY NEED TO BE INCREASED TO A 10 AMP FUSE TO ALLOW FOR THE LOAD CHANGE.

1. REMOVE LEFT FAIRING TRIM ACCENT BY SQUEEZING THE SIDES AND PULLING UPWARDS CAREFULLY.
2. OPEN LEFT POCKET DOOR AND REMOVE THE FOUR LOCK PINS IN EACH CORNER BY PRESSING DOWN THE CENTER WITH A SMALL FLATHEAD SCREWDRIVER, THEN PULL UPWARDS TO PULL OUT POCKET.
3. WITH THE POCKET REMOVED DRILL A 1-1/8" HOLE IN THE RIGHT SIDE DIAGONAL PANEL FOR '06 AND NEWER MODELS. FOR '01-'05 MODELS DRILL THE HOLE ON THE REAR WALL OF THE POCKET. THERE IS A MARK THAT LOOKS LIKE A CROSSHAIR ON THE BACKSIDE OF THE POCKET. THIS IS THE BEST PLACE TO DRILL.
4. UNSCREW THE NUT OFF THE USB SOCKET AND INSERT THE FRONT OF THE USB SOCKET THROUGH THE HOLE IN THE POCKET. THEN SCREW THE NUT BACK ONTO THE USB SOCKET UNTIL IT IS TIGHT AGAINST THE POCKET.
5. CONNECT THE WIRE HARNESS PROVIDED TO THE BULLET CONNECTORS ON THE USB SOCKET. CONNECT THE BLACK WIRE TO BLACK AND RED WIRE TO RED.
6. LOCATE THE RED MALE THREE PIN PLUG UNDERNEATH THE POCKET YOU REMOVED. PLUG THE WHITE THREE PIN CONNECTOR FROM THE USB SOCKET INTO THE RED THREE PIN PLUG ON THE BIKE.
7. SET THE POCKET BACK INTO PLACE AND REFASTEN BY PUSHING THE FOUR LOCK PINS BACK INTO THE FOUR CORNERS.
8. PUT THE FAIRING TRIM BACK ON, STARTING AT THE TOP AND WORKING DOWN PRESSING IT BACK INTO PLACE.

NOTE: SPLICE CONNECTORS NOT NEEDED FOR GL1800 INSTALLATION.

Scan code with
your smartphone
to view video

