

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

SADDLEBAG STAYS

PART NO. 53-450

HONDA

VT750 SPIRIT

Copyright© 2003 by Big Bike Parts, Inc.™ No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

TOOLS NEEDED: 12MM WRENCH 8MM ALLEN WRENCH

INSTALLATION:

1. REMOVE THE TWO FENDER STRUT SCREWS.
2. INSTALL THE SADDLEBAG STAY USING THE NEW LONGER SCREWS PROVIDED.
3. REPEAT STEPS 1 AND 2 FOR THE OTHER SIDE.