

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright © 2004 by Big Bike Parts, Inc.™ No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

PART NO. 82-203

CHROME SIDE COVERS
SUZUKI VL800 VOLUSIA

TOOLS NEEDED: 5MM ALLEN WRENCH
CRESCENT WRENCH

1. USING 5MM ALLEN WRENCH REMOVE THE SCREW FROM THE RIGHT SIDE COVER.
2. REMOVE THE RIGHT SIDE COVER AND REMOVE THE RUBBER GROMMET FROM THE SCREW HOLE AND PUT IT ON THE NEW COVER. INSTALL THE NEW COVER REUSING THE SCREW.
3. USE THE KEY TO TAKE OFF THE LEFT SIDE COVER.
4. USE A CRESCENT WRENCH TO REMOVE THE NUT ON THE KEY TUMBLER AND REMOVE THE TUMBLER. REMOVE THE GROMMET AROUND THE HOLE AND INSTALL IT ON THE NEW COVER. INSTALL THE KEY TUMBLER INTO THE HOLE.