

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

SADDLEBAG LID ORGANIZER
(PART NO. H15406)
TRUNK LID ORGANIZER
(PART NO. H15407)

FOR HONDA GOLDWING
GL1500/6 MODELS

Copyright© 1997 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.®

ITEMS REQUIRED: MEDIUM PHILLIPS SCREW DRIVER, 8MM SOCKET WRENCH

1. REMOVE THE OUTSIDE PHILLIPS MOUNTING SCREW FROM THE LID HATCH. (SEE SKETCHES ON BACK)
2. REINSTALL THE PHILLIPS SCREW WITH THE PLASTIC MOUNTING CLIP PROVIDED AS IF IT WERE A WASHER, LEAVING THE "S" HOOK HOLE POINTING IN TOWARDS THE LID.
3. FOR THE SADDLEBAG NETS: REMOVE THE TWO OUTSIDE NUTS HOLDING ON THE SADDLEBAG REFLECTOR/LIGHT USING THE 8MM SOCKET. REINSTALL THE 8MM NUT WITH THE PLASTIC MOUNTING CLIP PROVIDED AS IF IT WERE A WASHER.

FOR THE TRUNK NETS: REMOVE THE TWO PHILLIPS HINGE SCREWS ON THE BOTTOM OF THE TRUNK LID. REINSTALL THESE TWO PHILLIPS SCREWS WITH THE PLASTIC MOUNTING CLIPS PROVIDED AS IF THEY WERE A WASHER.
4. TAKE THE NETTING AND ATTACH "S" HOOKS TO THE SHOCK CORD AT EACH END OF THE WIDE NYLON STRAPPING AT THE TOP AND BOTTOM OF THE NETTING. THE "S" HOOKS SHOULD ALSO HOOK ONTO THE END OF THE NETTING AT THE SAME POINT TO HELP MAINTAIN THE NETS SHAPE.
5. NOW HOOK "S" HOOKS INTO PLASTIC CLIPS ALREADY IN PLACE, STRETCHING THE NET TAUGHT TO FIT.
6. REMEMBER , THE LONGER LENGTH NYLON STRAPPING GOES TO THE BOTTOM OF THE LID AND ON THE SADDLEBAGS THE MORE TAPERED END GOES FORWARD TO MATCH THE CONTOUR OF THE SADDLEBAG.