

BikeYoke DeHy- installation

Before assembling your DeHy, make sure your package contains all parts.

- 1x DeHy assembly
- 1x shift cable housing
- 2x housing endcap
- 1x shift cable
- 1x barrel cable clamp
- 1x shift cable endcap

BEFORE YOU GET STARTED:

- **WEAR SAFETY GLASSES AND SAFETY GLOVES AT ALL TIMES, WHEN WORKING ON YOUR SUSPENSION PARTS !!!**
- **WATCH OUR DEHY INSTALLATION VIDEO ON YOUTUBE OR IN THE „TECHNICAL INFORMATION“ SECTION OF OUR WEBSITE !!!**
You can find it here: <https://www.youtube.com/watch?v=OxGU6CqaBzQ>
- **IF THERE IS ANYTHING NOT CLEAR TO YOU: CONTACT US FIRST, BEFORE WORKING ON YOUR POST!**



1. Remove your Reverb seatpost from your bike and clean it properly
2. Remove the saddle clamp , using a 4mm Allen key
3. Remove the valve cap, using a 9mm socket
4. Release the air from your post. **ATTENTION: The high pressurized air may contain suspension fluid. Use a towel to cover escaping air!** Make sure the pressure is all out!
5. Remove the retaining ring from the bottom of your seatpost.
6. Slide the outside tube of the seatpost towards the post head, to get access to the poppet valve cover and poppet valve housing.
7. Unthread the poppet valve cover using a 10mm wrench. Hold up against the poppet valve housing using a 11mm wrench.
8. **ATTENTION: When taking off the poppet valve cover ,make sure,that the poppet valve itself stays completely inside the poppet valve housing. The poppet valve must not get out!** Dispose the extra oil of the hydraulic hose.
9. Screw on the DeHy adapter, using a 10mm wrench for the DeHy adapter and a 11mm wrench to hold up against the poppet valve housing. Torque: 6Nm!
10. Slide back the outer tube and secure it with the retaining ring. Make sure, the retaining ring sits in place properly!
11. Reinflate the post with 200-250psi, using a suitable shock pump and reinstall the valve cap, using a 9mm socket.
12. Congratulations! You´re done attaching the DeHy adapter to you Reverb!

Required free cable length:



When attaching the barrel cable clamp to the remote wire, make sure you pull on the end of the shift cable, so that there is no play in the remote lever. Then clamp the barrel at 12mm free wire length from the endcap!

13. Attach the barrel cable clamp to your DeHy adapter, and slightly grease the leverage.
14. Put the seatpost back into the seat tube and properly clamp the seatpost
15. Adjust the cable tension
16. Check, for smooth cable movement before every ride and replace or regrease, if necessary.

Before and during riding, always remember:

Safety first!!!

Check and make sure your Bike and your components are properly serviced and maintained!

