



# Bar End Mirrors and Bar End Mirror Adapters

**Parts Needed:**

- Bar end mirrors
- Bar end mirror adapters

**Weekend Project Category:**

- Appearance
- Beginner

**Fits The Following Motorcycles:**

- Triumph Modern Classics

**Difficulty:****Tools Required:**

- 5 mm Allen wrench
- Blue loctite

**Time it Takes to Install:**

- 10 minutes

**WARNING:** Laws concerning this product vary from state/province to state/province. Your state/province may prohibit its use on public roads or restrict its use to novelty, show use, off-road areas, or race facility areas only. In some states/provinces off-road uses are also prohibited. The manufacturer and retailer assume no responsibility for any use or application of this product in violation of any applicable law. Before installing this product, please check your state/province and local/municipal laws and regulations.

**WARNING:** It is recommended that this kit be installed by a certified Triumph technician, following the Triumph service manual to aid in proper fitting. Verify all torque specs in Triumph service manual.

## Related Weekend Project Upgrades

**Four Bolt Risers****Clubman Handlebars****Motogadget Mini Triple Clamp****Flat Gauge Bracket**



# Bar End Mirrors and Bar End Mirror Adapters



## Step 1: Remove Stock Mirrors

- Remove stock mirrors from controls setup. We recommend using BC Mirror Hole Caps to clean up the hole leftover from the original mounting points.



## Step 2: Assemble and Install Bar End Mirror Adapter

- Assemble bar end mirror adapter, and insert into end of hollow handlebar.
- Turn screw in adapter to expand adapter until it fits snugly inside handlebar and will not come out.



## Step 3: Install Bar End Mirror

- Loosen bar end mirror mounting ring and slide over bar end mirror adapter.
- Tighten bar end mirror over adapter. Blue Loctite is recommended.