



Custom Dynamics® Tour Pak® Quick Disconnect Harness Installation Instructions

We thank you for purchasing the Custom Dynamics® Tour Pak® Quick Disconnect Harness. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: CD-TP-QD-HD14

Package Contents:

- Tour Pak® Quick Disconnect Harness (2)
- Instructions

Fits: 1997-2013 Harley-Davidson® Electra Glide, Ultra Classic, Ultra Limited models (including CVO™), Road King (FLHR), Road King Classic (FLHRC), Road Glide Ultra (FLTRU) and Road Glide Ultra CVO™ (FLTRUSE), 1997-2009 Road Glide Standard (FLTR), 2006-2009 Street Glide (FLHX) and 2010-2013 Tri Glide® with the Add On 14-later style Tour Pak®.



ATTENTION

Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Installation:

1. Secure motorcycle on level surface. Remove seat. Disconnect negative battery cable from the battery.
2. Locate and unplug the lighting connector to the rear fender.
3. Plug the Tour Pak® Quick Disconnect Harness, in-line, into the rear lighting harness and into the bike's main wiring harness.
4. Secure the Tour Pak® Quick Disconnect Harness under the seat from becoming cut, frayed, or pinched.
5. Plug the Tour Pak® Quick Disconnect Harness into your 14-later factory Tour Pak® harness.
6. Reconnect the negative battery cable to the battery.
7. Reinstall motorcycle seat and test operation of all lighting before riding.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST