

Custom Dynamics® Shark Demon® 2 Rock Guard Installation Instructions



We thank you for purchasing the Custom Dynamics® Shark Demon® 2 Rock Guard. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: SD2-GUARD-C

Package Contents:

- Shark Demon® 2 Rock Guard, Clear (1)
- Instructions (1)



Fits: Compatible with most Custom Dynamics® Shark Demon® 2 LED Lights. Except SD2-7-13 (2001-2925) and SD2-7-14 (2001-2926) (**sold separately**).

Installation:

1. Install Shark Demon® 2 Rock Guard by snapping into place over the Shark Demon® 2 LED Light. Shown in **Figure 1**.



2. Test the Custom Dynamics® Shark Demon® 2 LED Light with Shark Demon® 2 Rock Guard for proper operation.

⚠ ATTENTION ⚠

Please read all Information below before Installation

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Cleaning: Take special care in cleaning the finish. Never use abrasive polishes or cleaners as these can scratch and/or damage the finish. Avoid power washing/applying direct stream to aftermarket parts.

Note: Do not trailer vehicle backwards with Rock Guards installed, wind could blow Rock Guard off Shark Demon® 2 LED.