

Custom Dynamics® Indian® Wiring Adapter Installation Instructions

We thank you for purchasing the Custom Dynamics® Indian® Wiring Adapter. Our products utilize the latest technology and highest quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: MPR-IND

Package Contents:

- Indian® Wiring Adapter

Fits: 2020-2022 Indian® Challenger, Challenger Dark Horse & Challenger Limited, 2015-2022 Chieftain, Chieftain Dark Horse, Chieftain Limited, Chieftain Elite, Springfield, Springfield Dark Horse, Roadmaster, Roadmaster Dark Horse & Roadmaster Limited, 2015-2021 Chieftain Classic, Roadmaster Classic & Roadmaster Elite, 2015-2020 Chief Classic & Chief Vintage, 2021 Vintage & Vintage Dark Horse, 2015-2022 Chief, Chief Dark Horse, 2022 Chief Bobber & Chief Bobber Dark Horse.





ATTENTION



Please read all Information below before Installation

Warning: The auxiliary power circuit is power even when the bike is off. Its is critical to disconnect the negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

<u>Safety First</u>: Make sure the bike is parked on a level surface and bike's mechanical components are cool to the touch.

Installation:

- Secure motorcycle on level surface. Confirm the ignition switch is in the off position. Remove the seat and disconnect the negative [-] battery cable from the battery.
- 2. Locate the rear fender lighting harness connectors under seat.
- 3. Unplug the connectors and plug the Indian® Wiring Adapter inline with the rear fender lighting harness..
- 4. Connect wires as needed using installed Posi-Locks.

Black—Constant Ground

Blue- Running

Red— Brake

Orange—Aux Power

Brown—Right Side Switched Ground

- -Right Run/Brake/Turn (Models Without Center Taillight)
- -Right Turn Only (Models With Center Taillight)

Purple—Left Side Switched Ground

- —Left Run/Brake/Turn (Models Without Center Taillight)
- —Left Turn Only (Models With Center Taillight)
- 6. Re-install seat and re-disconnect the negative [-] battery cable from the battery.
- 7. Check operation of all lights.

