

FEEL THE HEAT!

Defender SS Mirrors

Part # 04-0038	1-3/4" Clamp Defender SS Mirror	Black
Part # 04-0041	1-7/8" Clamp Defender SS Mirror	Black
Part # 04-0039	2" Clamp Defender SS Mirror	Black

Congratulations on your purchase of the Defender SS Side Mirrors! Billet aluminum side mirrors don't only look great, but they are very functional. The downside is when they stick out far enough to prevent your vehicle from fitting in an enclosed trailer or from passing the 50" trail width pylon. The Defender SS Mirrors have been designed to fold in and provide the additional room necessary to fit in tight spots and return to their original position when you are ready. No need to mess with adjusting them back into place, they have detents to lock them back to where they need to be. Be sure to check out the full line of DragonFire Accessories for your vehicle at your local authorized dealer or online at <http://www.DragonFireRacing.com>

Defender Mirror is designed to be folded in by hand to avoid collision. High speed impact may damage mirror.



- Read and understand these instructions before installing product
- Installation may scratch cage where attached
- Do not over tighten hardware on aluminum components
- Do not use product if there are any signs of damage

Tools Required

5/32" Allen

3/16" Allen

Disclaimer

Off road activities can be hazardous and could lead to injury, dismemberment, paralysis and death. No warranty of representation is made as to the products ability to protect the user from any injury or death. The user assumes that risk. The acceptance and /or use of this merchandise purchased from DragonFire by the customer hereby shall release DragonFire from any and all liability pertaining to the use of such merchandise.

Step 1: Place vehicle on a flat and level surface. Place gear selector in "Park" and remove keys from the ignition.

Step 2: Remove two bolts retaining outside cage clamp half. Set outside clamp half and hardware aside they will be re-used. (Figure A)

Step 3: Loosen inner rotation bolt to allow clamp half to rotate on the arm. (Figure B)

Step 4: Place clamp flush against cage to identify desired viewing angle. (Figure C) Once desired location and angle have been reached, hold pieces in place and securely tighten inner rotation bolt to 80 in-lbs.

Note: Step 4 for may require assistance from an additional person to hold mirror while primary driver sits in the driver's seat.

Part Identification: Only driver side mirror will have DragonFire logo etched on the front of the mirror arm.



Step 5: Place mirror back on the cage and attach clamp half removed in Step 2. Leave clamp loose to adjust position.

Step 6: Position mirror on vehicle to desired viewing angle and tighten clamp bolts evenly. Torque bolts to 45 in-lbs. (Figure D)

Step 7: Repeat Steps 2 through 6 for opposite side of vehicle.

Step 8: This completes installation. Time to ride and enjoy!

Note: If mirror begins to move excessively, check fastener on arm joint. Torque to 57 in-lbs if necessary. (Figure E)



ProTip: Periodically check all hardware and re-tighten if needed.

For further assistance, please contact your authorized DragonFire dealer.