

SXS
PERFORMANCE PRODUCTS

DRT
MOTOR SPORTS

INSTALLATION GUIDE



HOOD SCOOP FOR POLARIS 2025+ PRO SERIES (PRO R, PRO S, PRO XP)

INSTALLATION GUIDE

- 1. REMOVE THE FACTORY HOOD.**
- 2. INSTALL THE DRT BAFFLE OVER THE CLUTCH INTAKE. ALIGN THE BAFFLE WITH THE OEM HOOD SCREW HOLE LOCATIONS. THE FORWARD PLATE WITH PRE-INSTALLED NUTSERTS IS OPTIONAL. FOR INCREASED AIRFLOW TO THE CLUTCHES, REMOVE THIS PANEL.**
- 3. ATTACH THE TABBED BRACKET. POSITION THE BRACKET WITH TWO TABS THAT LOCATE THE FRONT OF THE HOOD TO THE DRT HOOD SCOOP. USE THE PROVIDED TWO BUTTON-HEAD SCREWS AND WASHERS. REFERENCE PICTURES FOR CORRECT PLACEMENT.**
- 4. INSTALL THE DRT HOOD. FIRST, SLIDE THE FORWARD TABS INTO THE OEM PLASTICS. REST THE REAR OF THE HOOD ON THE INSTALLED DRT BAFFLE. SECURE USING TWO BUTTON-HEAD SCREWS WITH WASHERS INTO THE BAFFLE. DO NOT OVERTIGHTEN EXTERIOR HARDWARE.**

