

# **POLARIS RANGER RZR 900 XP**

## **REAR RECEIVER**

**2" Receiver**

**PART # 100855**

**Kit Components:**

<u>Qty</u>	<u>Part Description</u>
1.....	2" Receiver

**Recommended Tools:**

- Hydraulic jack
- 17MM open end wrench
- 17MM socket & ratchet



### **INSTALLATION INSTRUCTIONS:**

1. Place jack under machine frame and raise back end high enough that tension is relieved from the rear struts.
2. Remove one bolt at a time. The RZR frame has cutouts on bottom for wrench access to the lower nuts. Hold the nut with a wrench as the bolt is pulled through to avoid losing the nut under the skid plate. Repeat this process for the remaining bolts.
3. Remove OEM cover plate.
4. Install receiver assembly by working one bolt at a time. Start with the upper bolts. For the lower bolts, carefully hold the nut with a wrench while simultaneously positioning the strut and running the bolt through all components. Do not fully tighten the nut at this time.
5. Repeat process for remaining bolt. You may find it helpful to have the assistance of another person to hold or spread the struts/wheels. Also raising or lowering the jack can help to pull holes into alignment.
6. Tighten all hardware evenly.

