



FLARE™ WINDSHIELD FOR YAMAHA STRATOLINER



EMAIL:
info@getklocked.com



CALL:
(605) 996-3700

1. Loosen the four windshield trim fasteners and remove the trim and the stock windshield
2. Clean the trim and fairing of any loose dirt to prevent scratching
3. Install your new Flare windshield with the hardware and trim removed in step 1 and torque to factory specification



CORRECT



INCORRECT

* A misaligned or incorrectly installed windshield, can cause damage around the mounting hole.

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.

QUALITY, PERFORMANCE & COMFORT.



KLOCK WERKS KLEANING PRODUCTS

We tested many products, and found a company that would combine what we like and remove what we didn't like to create a complete Kleaning product line-up.

- // The recommended cleaner for your Flare™ Windshield
- // Proprietary concoction designed by REAL riders
- // Protects surfaces while repelling dirt
- // Complete line for all finishes
- // Clean, Shine, and protect - just about anything.



WWW.GETKLOCKED.COM

EXCLUSIVE OFFER

FREE *Test Pilot* SHIRT

We like hearing from our customers, and we love seeing where you take your Flare™ Windshield. Visit us online, fill out our handy form, upload a photo of you with your installed Flare™ and we'll send you a **FREE T-SHIRT!**

1. Visit WWW.GETKLOCKED.COM/OFFERS
2. Fill out the form and enter your code: STRAT166174
3. Your FREE tee will soon be on its way!

OFFER AVAILABLE WHILE SUPPLIES LAST.

