



FLARE™ WINDSHIELD FOR VICTORY



EMAIL:
info@getklocked.com



CALL:
(605) 996-3700



1. Using a 4mm Allen wrench, remove the four fasteners that hold the stock windshield to the mount brackets.

NOTE: For installation on the Cross Country Tour, the Touring windshield brackets and the rubber support strips between the front and inner fairings need to be removed.



2. Remove the stock windshield and replace it with the new Klock Werks Flare Windshield. Align the holes in the windshield to the mount points on the windshield brackets.



3. Carefully install the hardware removed in step 1 and torque them evenly to 50-60 in-lbs

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.

MORE WAYS TO KLOCK YOURSELF OUT



KLOCK WERKS **KLEANING PRODUCTS**

**YOU WON'T BELIEVE
HOW GOOD THIS
STUFF WERKS!**

We even use it on our glasses, at home, in our car, and of course on the Flare™ Windshield!

We tested many products, and found a company that would combine what we like and remove what we didn't like to create

- // The recommended cleaner for your Flare™ Windshield
- // Proprietary concoction designed by REAL riders

- // Protects surfaces while repelling dirt
- // Complete line for all finishes
- // Clean, Shine, and protect - just about anything.

