

CUSTOMER COPY



FLARE™ FOR KAWASAKI VAQUERO

CAUTION:

Do not use petroleum based or ammonia based cleaners including rainsheeting products on Klock Werks windshields. They can cause dulling and hazing, and in some cases, fractures in the material. Failure to maintain your polycarbonate windshield can result in damage.

QUESTIONS?



EMAIL:
info@getklocked.com
CALL: (605) 996.3700



1. Remove the 5 stock fasteners that secure the stock windshield to the motorcycle.



2. Ensure that the inner and outer fairing are aligned so that you can see the brass inserts before installing your Flare™ Windshield.



3. Install your new Flare™ Windshield with the hardware removed in step 1 and torque to factory specifications.

CAUTION: Klock Werks cannot be held responsible for any damage to painted surfaces during removal or addition of Klock Werks parts.