



Installation Instructions

**KODLIN Lower Riser for Harley-Davidson Milwaukee 8 Breakout Models
K55117 / K55118**

All bolts have to be installed with medium strength thread locker (i.e. Loctite®)!

Suggested tools: ¼" Allen wrench, ¾ wrench, ¾ socket set and ratchet

1. Securely lift up the motorcycle
2. Cover the gas tank and front fender to prevent any damage
3. Remove the bolts and the stock top riser clamp (speedometer housing)
4. Rest the handlebar on the covered gas tank
5. Remove the bolts and the stock lower risers.
6. Install the new KODLIN Lower Risers (30 - 40 ft lb)
7. Place the handlebar back up on the new risers and install the stock top riser clamp (12 – 15 ft lb)

Turn the handlebars all the way to the left and then right checking for any pulling or binding of the wires, hoses, or cables.

NOTE: No warranty coverage is provided by Kodlin that is due to improper installation or lack of maintenance. Periodic maintenance and inspection are required. It is the installer's responsibility to ensure that all the fasteners are tightened before operation of the motorcycle. We recommend following the manufacturers torque specs.