

INSTALLATION

VACUUM POD REBUILD KIT

8554/8580

PARTS INCLUDED

Diaphragm and Rod Assembly 1

1 Pod Assembly

Spring 1

E-Clip 1

Washer 1

Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING

THE CONTENTS DESCRIBED HEREIN CAN RESULT IN

POTENTIAL DEATH OR SERIOUS INJURY.

ATTENTION! This indication alerts you to the fact that ignoring the contents

described herein may negatively affect product performance and

functionality.

CAUTION! This indication alerts you to the fact that ignoring the contents

described herein can result in potential injury or material

damage.

TOOLS SUGGESTED

Flat Blade Screwdriver, Set of Combination Wrenches, Set of Hex Wrenches

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the

installation. Park the motorcycle on a hard, level surface and turn off the

ignition. Let cool.

WARNING! YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST

SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE

AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT

INJURY.

STEP 2 Remove the Hypercharger from the motorcycle using the installation

instructions as a guide. If you do not have the instructions, they are available

on our website, www.kuryakyn.com.

-cont.-

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com or call 715.247.2983

LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- · Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
 - •The product must be properly installed, maintained and operated under normal conditions.
 - Kürvakvn makes no warrantv, expressed or implied, with respect to any gold plated
- •Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breech of contract or duty between Kürvakvn and a customer.
- Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- •Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Küryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to: control modules, wiring, chrome & other components.
- •Küryakyn makes no warranty of any kind in regard to other manufacturer1s products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

For purchasing Küryakyn® products, you can receive a complete catalog free of charge. Send the Proof-of-Purchase below with your address to: Küryakyn, P.O. Box 339, Somerset, WI 54025


Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved.



- Küryakyn
- **STEP 3** Remove the three retaining screws from the vacuum pod plate on the backside of the Hypercharger. Set these aside, they will be reused.
- **STEP 4** Remove the spring and pod assembly from the housing.
- **STEP 5** Remove the E-Clip and washer from the end of the diaphragm rod that is connected to the butterfly shaft. Remove the Diaphragm and Rod.
 - NOTE: Pay attention to the orientation of the of the hoop on the butterfly shaft that the Rod Assembly attaches to. The new Assembly will need to be attached in the same orientation or the butterflies will operate incorrectly.
- **STEP 6** Install the new Diaphragm Rod Assembly to the butterfly shaft using the provided E-Clip and Washer.
- **STEP 7** Install the Pod Assembly in the housing making sure that the Diaphragm lays flat underneath it and is tucked in around the edge.
 - **NOTE:** When performing the following Step, keep pressure on the butterflies or diaphragm rod to ensure that the pressure from compressing the spring does not push the diaphragm out of place.
- **STEP 8** Install the new spring and replace the pod plate. Secure with the three screws removed in Step 3.
- **STEP 9** Install the Hypercharger to the motorcycle. Plug in the vacuum hose.
- ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.



PAGE

2

Ride On!