

# Instructions for Linbar<sup>®</sup>, Multibar<sup>®</sup> and Unibar<sup>®</sup> Part # 609-1, 13609, 14609

Fits Yamaha Stryker 2011-Present



www.lindbycustom.com  
320 E. Crowther Ave., Placentia, CA 92870  
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove left and right floorboards and install flat stock brackets between frame and bracket for the floorboards. Do not tighten bolts yet.
2. Install the 2 top mounts of the Highway bar to the two 6mm bolts above the radiator. (install spacers between the frame and highway bar). Do NOT tighten bolts yet.
3. Connect the lower mounts of the highway bar to the previously installed flat stock brackets.
4. Tighten all the bolts to the manufacturer's Specifications.
6. Hardware included:
  - 2 x 6mm x 25mm 1.0
  - 2 x 10mm x 80mm 1.25
  - 2 x 10mm x 90mm 1.25
  - 2 x Spacers 3mm by 10mm I.D.
  - 2 x 3/8" 16 x 2 "
  - 2 x 3/8" 16 x 2 1/2"
  - 4 x 3/8 nylon lock nuts
  - 2 x 6mm flat washers
  - 8 x 3/8 flat washers
  - 2 Flat stock brackets w/ 4 holes

