



RM4 PLOW MOUNT INSTRUCTIONS

15-18 Sportsman 570 & SP

16-17 Sportsman 450 / 570 / 570 Touring / X2

PART# 4501-0812

The RM4 Mount Kit is designed to allow for quick removal when not needed for plowing. This mount design uses the machine's front bumper and/or frame member to push against and distribute the load when plowing.

Remove the two bolts under the machine just behind the tow loop.

Slip mount in place over tow loop and attach with the two 5/16" x 1" hex bolts and washers to the location where you just removed the first bolts. Leave loose.

Attach the back corner of the mount using the two 1/4" x 3/4" x 2-1/4" round U-bolts going over frame tube. Use the block spacers in this location as well. The black spacers will go between the mount and the frame tubes, use two on each side. The U-bolt will go over the frame tube and through the black spacers and the mount. Use the 1/4" washers and nylocks nuts to secure.

Winch lift bracket attaches to the front of machine as shown. Use the spacer tubes and the 1/4" x 2-1/4" hex bolts with flat washers.

Align and tighten mount securely.

NOTE: On newer models, on the lower portion of the plastic grille, you will need to remove the two bolts and trim/cut out the that portion of plastic so the mount can slide on all the way.

NOTE: The 1/2" bolts and nuts in the removable mount are now pre-assembled in the push tubes. The 1/2" hitch pin is in the push tube hardware kit.

**FOR QUESTIONS OR COMMENTS PLEASE CALL: 320-964-1616
(7:00 to 4:30 CST Monday through Thursday).**

PART #	QTY.	Description
2595-100	1	RM4 Plow Mount
KD100	1	Removable Mount
2595-4	4	Block Spacer
2595-5	1	Winch Lift Point Bracket
HDW9199	2	1/4 x 3/4 x 2-1/4 Rd. U-Bolt
HDW2051	2	5/16 x 1 Hex Bolt
HDW9002	2	5/16 Flat Washer
HDW7050	4	1/4 Nylock Nut
HDW9012	6	1/4 Flat Washer
HDW9185	1	1/2 Cotterless Hitch Pin
HDW2006	2	1/4 x 2-1/4 Hex Bolt
HDW9405-BLK	2	5/8 rd x 1-1/4 lg Spacer

