



ITEM	PART#	QTY.	DESCRIPTION
1	2715-70	1	Bottom Mount Weldment
2	HDW2154	4	5/16 x 1-1/4 x 2 Rd. U-Bolt
3	HDW9002	8	5/16 Flat Washer
4	HDW7058	8	5/16 Nylock Nut

PLOW MOUNT INSTALLATION INSTRUCTIONS
HONDA 93-00 TRX 300 / 97-17 250 RECON

PART# 4501-0594

Install the bottom mount to ATV as shown.
Place the u-bolt around frame tubes then hold
Mount up in place and use the flat washers and
The nylock nuts to secure. Align mount and tighten.

Some models will have a skid pan you may remove
Or you can mark and drill through to mount with
Skid pan in place.

