



ITEM	PART#	QTY.	DESCRIPTION
1	2717-100	1	Bottom Mount Weldment
2	HDW2158	4	5/16 x 1-3/8 x 2-3/16 Rd. U-Bolt
3	HDW9002	8	5/16 Flat Washer
4	HDW7058	8	5/16 Nylock Nut

PLOW MOUNT INSTALLATION INSTRUCTIONS

PART# 4501-0595

HONDA

04-17 Rancher 420 / Foreman 14-17
500 Rubicon 15-18

Remove the skid plate. Place the u-bolts over the frame tubes as shown. The back one must go in the foot peg channel of the floor board support. The front has two sets of holes for different models, the back set is for 2014 and newer straight axel models.

If you would like to keep the factory skid plate on you will have to mark and drill to bolt the mount over the skid plate.

