



**PLOW BOTTOM MOUNT INSTALLATION
INSTRUCTIONS**

2013-2014 KYMCO MXU 500/700
2017 ARCTIC CAT ALTERRA 400
PART# 4501-0606

Qty.	PART#	DESCRIPTION
1	2738-100	Plow Bottom Mount
4	HDW2158	5/16 x 1-3/8 x 2-3/16 U-Bolt
8	HDW9002	5/16 Flat Washer
8	HDW7058	5/16 Nylock Nut

Customer should receive a copy of this instruction sheet at time of purchase if installed by dealer or another party.

Remove skid plate if needed. If skid plate is left on, you need to drill holes for the U-bolts to go through.

Hang U-bolts over frame tubes on either side of the foot bracket or floor board support as shown.

The Kymco will use the far outside holes as the Arctic Cat will use the inner set of holes that align with the U-bolts.

Once plow mount is on, place the flat washers and nylock nuts on. Align and tighten. Recheck after usage.



KYMCO



ARCTIC CAT



FOR QUESTIONS OR COMMENTS PLEASE CALL: 320-964-1616 (7:00 to 4:30 CST Monday through Thursday).