



**YAMAHA WOLVERINE
PLOW MOUNTING INSTRUCTION
P/N: 4501-0638**

QTY.	PART #	DESCRIPTION
1	2774-100	PLOW MOUNT
2	HDW9424	1/2 x 3 Spacer Blocks
2	HDW9411	TUBE SPACERS 5/8 X 7/8
2	HDW2056	5/16 X 2 HEX BOLTS
2	HDW2073	5/16 X 1-1/2 X 3-1/2 SQ. U-BOLT
6	HDW7058	5/16 NYLOCK NUT
6	HDW9002	5/16 FLAT WASHER
1	INST2774	INSTRUCTION SHEET

ATTACH BOTTOM MOUNT TO FRAME PER PICTURE.

PLACE THE SQUARE U-BOLTS AROUND FRAME TUBES. HOLD MOUNT UP IN PLACE TO ATTACH TO THE U-BOLTS WITH THE SPACER BLOCKS BETWEEN THE FRAME AND THE PLOW MOUNT, PLACE WASHERS AND NYLOCK NUTS ON U-BOLTS BUT LEAVE LOOSE.

ATTACH BACK PORTION OF PLOW MOUNT TO FLOOR BOARD SUPPORT USING THE 5/16 X 2 HEX BOLTS, WASHERS AND NYLOCK NUTS GOING UP THROUGH THE MOUNT WITH THE TUBE SPACER BETWEEN THE PLOW MOUNT AND FLOOR BOARD SUPPORT. PLACE WASHER AND NUT ON BOLT ON THE INSIDE OF THE FLOOR BOARD SUPPORT.



FRONT

ALIGN MOUNT AND TIGHTEN ALL HARDWARE.



CUSTOMER MUST RECEIVE A COPY OF THIS INSTRUCTION SHEET AT TIME OF PURCHASE.

