



MOOSE BOTTOM MOUNT PLOW INSTRUCTIONS
CAN-AM DEFENDER
PART# 4501-0872

ITEM	PART#	QTY.	DESCRIPTION
1	2825-70	1	Plow Mount Weldment
2	HDW2073	2	5/16 x 1-1/2 x 3-1/2 Sq. U-Bolt
3	HDW9035	2	5/16 x 2-1/2 Hex Bolt
4	HDW7058	6	5/16 Nylock Nut
5	HDW9002	8	5/16 Flat Washer

Attach Bottom Mount to UTV as shown in pictures.

The U-Bolts will go over frame tubes right behind the trailing arm bracket and through a gap between front skid pan and rear skid pan.

The back tabs will line up with holes in the floor board support frame tube. (NOTE: On models with plastic skid plate There will be a line on the skid plate and these places will need to be cut out to get mount to fit up properly.)

Use the 5/16 x 2-1/2 hex bolts on the rear tabs to bolt up to floor board frame with a washer on each side of the bolt.

Use the 5/16 Nylock Nuts to secure all bolts and align and tighten.

Push tube will pin up with the wire loop pins supplied
With the push tube kit.

Questions or Comments Call 320-964-1616
Monday thru Thursday 78:00 to 4:30 CST

