

WINCH MOUNT INSTRUCTIONS


03-17 Honda 650/680 Rincon

PART# 4505-0642

ITEM	QTY.	PART#	DESCRIPTION
1	1	1524-1	Main Winch Plate
2	4	HDW2004	1/4 x 1-3/4 Hex Bolt
3	2	HDW2050	5/16 x 3/4 Hex Bolt
4	4	HDW7050	1/4 Nylock Nut
5	3	HDW7058	5/16 Nylock Nut
6	1	HDW2072	5/16 x 1 Button Head Bolt
7	4	HDW9407	7/8 U-Clamp

(Roller fairlead is not included with this kit)


- 1. Remove front lower skid pan. Remove the two middle bumper support bolts and retain for later use.
- Place winch mount on top of bumper support tubes. The front of the mount should be behind the front bumper tubes.
- 3. Attach back of mount using the two factory middle bumper support bolts.
- Place u-clamps around middle bumper support tube and attach to winch mount per illustration using two 1/4" x 1-3/4" hex bolts and 1/4" nylock nuts.
- Place two u-clamps around the upper bumper tube and attach to the winch mount above the roller fairlead mounting area. Secure with two 1/4" x 1-3/4" hex bolts and 1/4" nylock nuts.
- Tighten all bolts.
- Attach winch to the top of the winch mount with the hardware provided with the winch. Note: Some winches with the longer motors will require the plastic radiator shroud to be trimmed for clearance.
- When installing a two bolt pattern winch, use the provided 5/16" x 1" button head bolt in the front (closest to the fairlead) bolt hole.
- Attach the roller fairlead (Not included) to the front
 of the mount using two 5/16" x 3/4" hex bolts and
 two 5/16" Nylock nuts. (Rollers should turn freely.)
 Note: Bottom roller may need to be removed
 to run wire rope through. Tighten all bolts.
- Using the instructions provided with the winch, wire accordingly.





WINCH MOUNT INSTALLATION INSTRUCTIONS

03-17 HONDA 650/680 RINCON PART# 4505-0642



FOR QUESTIONS OR COMMENTS PLEASE CALL: 320-964-1616 (7:00 to 4:30 CST Monday through Thursday).