



PLOW MOUNT INSTALLATION INSTRUCTION
POLARIS RANGER 500 (mid size)
4501-0884

ITEM	PART#	QTY.	DESCRIPTION
1	2821-70	1	Plow Mount Plate
2	HDW9063	4	5/16 x 1-1/2 x 4-1/4 Sq. U-Bolt
3	HDW7058	8	5/16 Nylock Nut
4	HDW9002	8	5/16 Flat Washer

Remove plastic skid plate.

You may mark where the plow mount goes and then mark the skid plate and drill the skid plate so you can place the mount on the outside of skid plate. You also may have to loosen floorboards up so you can pry up on them to get the front U-bolts up around the frame tube.

Place the U-bolts around frame as shown and bolt the plow mount up onto the U-bolts using the nylock nuts and flat washers. Align and tighten.

Watch for any small brake line on back side of frame tube and make sure you move them out of the way.

Push tube will pin up to the mount with the wire loop pins that came in the push tube kit.



QUESTIONS OR COMMENTS CALL 320-964-1616 MONDAY thru THURSDAY 7:00 to 4:30 CST
INST2821PF