



Installation Instructions for Mustang Tank bib on 2010-2011 Honda VT1300 Sabre, Stateline, and Interstate

Installation of tank bib

1. Remove seat from bike.
2. Locate and loosen two screws at front end of dash panel. Remove screw at base of gas tank.
3. Slide tank bib into place, on top of wire harness, and under edge of dash panel.
4. Align lower end of bib and insert screw at base of gas tank, tighten. Tighten screws at front end of dash panel.
5. Replace seat.



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Ref. part #'s 93219, 93220, 93350, 93351