

MODEL & SADDLEBAG FIT

SOFTAILS	MODEL	YEARS	FITS	NEEDS RELOCATION	NOTES*
<i>Blackline</i>	<i>FXS</i>	<i>2010-2012</i>		●	
<i>Night-train</i>	<i>FXSTB</i>	<i>2000-2009</i>	●		
<i>Springer</i>	<i>FXSTS</i>	<i>2000-2007</i>	●		
<i>Cross Bones</i>	<i>FLSTSB</i>	<i>2008-2011</i>	●		
<i>FatBoy</i>	<i>FLSTF</i>	<i>2000-2017</i>	●		
<i>FatBoy</i>	<i>FLFB</i>	<i>2018 ></i>	●		
<i>Deluxe</i>	<i>FLSTN</i>	<i>2005-2017</i>	●		
<i>Deluxe</i>	<i>FLDE</i>	<i>2018 ></i>	●		
<i>Breakout</i>	<i>FXSB</i>	<i>2013-2017</i>	●		
<i>Breakout</i>	<i>FXBR</i>	<i>2018 ></i>	●		
<i>Standard</i>	<i>FXST</i>	<i>2000-15 new 2020</i>	●		
<i>Standard Custom</i>	<i>FXSTC</i>	<i>2007-11 & 2014</i>	●		
<i>Softail Slim</i>	<i>FLS</i>	<i>2012-17</i>	●		
<i>Softail Slim</i>	<i>FLSL</i>	<i>2018 ></i>	●		<i>1.5mm washer</i>
<i>LowRider</i>	<i>FXLR</i>	<i>2018 ></i>	●		<i>1.5mm washer</i>
<i>Street Bob</i>	<i>FXBB</i>	<i>2018 ></i>	●		<i>1.5mm washer</i>
<i>Fat Bob</i>	<i>FXFB</i>	<i>2018 ></i>	●		<i>1.5mm washer</i>
<i>LowRider</i>	<i>FXDL</i>	<i>2000-17</i>	●	●	
<i>Wide Glide</i>	<i>FXDWG</i>	<i>2000-17</i>	●	●	
<i>Street Bob</i>	<i>FXDB</i>	<i>2006-17</i>	●	●	
<i>Fat Bob</i>	<i>FXDF</i>	<i>2008-17</i>	●		<i>Contact Nelson Rigg for Hardware</i>
<i>Super Glide</i>	<i>FX</i>	<i>2000-2012</i>	●	●	
<i>Super Glide Custom</i>	<i>FXD</i>	<i>2005-2015</i>	●	●	
Metric					
<i>Kawasaki Vulcan S</i>		<i>2015 ></i>	●		
<i>BMW R18</i>		<i>2021 ></i>	●		