

# NEW RAGE CYCLES

## INSTALLATION INSTRUCTIONS

### KTM 790 DUKE

#### FRONT TURN SIGNALS

- 1 Remove T25 torx bolt and tilt headlight down. (Picture 1)
- 2 Unplug connector behind headlight, and remove (1) T30 torx bolt up top, and (2) T20 torx bolts below. (Picture 2)
- 3 Remove cover and unplug white turn signal connectors.
- 4 Remove (1) T30 torx bolt on each side to get to the mounting hardware underneath. (Picture 3)
- 5 Remove nut with a 12mm wrench and take off stock blinker. (Picture 4)
- 6 Remove top plate on new turn signal, and install lower bracket and lens onto the bike with provided M5x12 bolt and M5 nut. (Pictures 5/6)
- 7 Screw top bracket onto turn signal.
- 8 Plug in connectors and test.
- 9 Reinstall turn signals cover, headlight shield, and plug headlight back in.

