

INSTRUCTIONS

- 1) Install bar. Top bar clamp bolts tighten down to stem body with no gap. Bottom bar clamp bolts will have a gap. Torque bolts to 6Nm
- 2) Install stem onto steerer, align and tighten top 2 steerer bolts (9Nm).