

## **2015 Ranger XP Mid Size 2 Piece Roof Installation**

### Components:

- 2 Roof sections (R&L)
- 1 Roof Filler
- 2 Roll of Adhesive Foam Seal
- 14 1/4"-20x 3/4" Long Bolts
- 10 1/4"-20 Acorn Nuts
- 20 1/4" Flat Washer
- 4 1/4"-20 Nylock Nuts
- 4 1/4" x 1" Fender Washers

### Tool Required:

- 2 7/16" End Wrenches or Sockets
- 1 Drill
- 1 5/16" drill bit

1. Place the Adhesive Foam Seal on each cut edge of the roof and trim to length



2. Place roof sections together, set Roof filler on top, and secure one to the other with 1/4"-20x 3/4" long bolts through the top side with a 1/4" flat washer on top and bottom and the 1/4"-20 acorn nut on the bottom side of the roof.
3. Place the roof on the Vehicle, then center front to back and side to side. Mark holes from bottom side in the rear pocket area, remove and drill 5/16". Loosely secure rear corners with 1/4"-20x 3/4" long bolts, 1/4" x 1" fender washer, 1/4"-20 nylock nut. Mark front holes from the bottom side, remove and drill 5/16". Loosely install hardware in all 4 corners, makes sure roof is centered and tighten bolts.

