



INSTRUCTIONS FOR GUN HOLSTER BRACKET CLIP

Parts Index

- A . RAM HANDGUN HOLSTER BRACKET CLIP (QTY. 1)
- B. #10-24 X ½ BLACK PHILIPS DRIVE STEEL MACH. SCREW (QTY. 3)
- C. #10-24 BLACK THIN STAINLESS STEEL NYLOCK NUT (QTY. 3)
- D. 1/4"-20 X ½" BLACK CARRIAGE BOLT (QTY. 1)
- E. 1/4"-20 BLACK STEEL WING NUT (QTY. 1)




1. ATTACH BALL BASE TO BACK OF (A) BRACKET CLIP USING (B) SCREWS AND (C) NUTS.



2. SLIDE (A) BRACKET CLIP THROUGH BELT INSERT ON HOLSTER.



3. INSERT (D) CARRIAGE BOLT FROM UNDER BRACKET CLIP THROUGH BOTH SQUARE HOLES. PRESS ENDS OF BRACKET TOGETHER AND TIGHTEN (E) WINGNUT ONTO (D) CARRIAGE BOLT.



**HOLSTER NOT INCLUDED
BALL BASE MAY NOT BE INCLUDED**



National Products, Inc., 8410 Dallas Ave S., Seattle, WA 98108, (206) 763-8361 www.ram-mount.com

RMR-INS-GUN1


INSTRUCTIONS FOR GUN HOLSTER BRACKET CLIP

Parts Index

- A . RAM HANDGUN HOLSTER BRACKET CLIP (QTY. 1)
- B. #10-24 X ½ BLACK PHILIPS DRIVE STEEL MACH. SCREW (QTY. 3)
- C. #10-24 BLACK THIN STAINLESS STEEL NYLOCK NUT (QTY. 3)
- D. 1/4"-20 X ½" BLACK CARRIAGE BOLT (QTY. 1)
- E. 1/4"-20 BLACK STEEL WING NUT (QTY. 1)




1. ATTACH BALL BASE TO BACK OF (A) BRACKET CLIP USING (B) SCREWS AND (C) NUTS.



2. SLIDE (A) BRACKET CLIP THROUGH BELT INSERT ON HOLSTER.



3. INSERT (D) CARRIAGE BOLT FROM UNDER BRACKET CLIP THROUGH BOTH SQUARE HOLES. PRESS ENDS OF BRACKET TOGETHER AND TIGHTEN (E) WINGNUT ONTO (D) CARRIAGE BOLT.



**HOLSTER NOT INCLUDED
BALL BASE MAY NOT BE INCLUDED**



National Products, Inc., 8410 Dallas Ave S., Seattle, WA 98108, (206) 763-8361 www.ram-mount.com

RMR-INS-GUN1