

⚠️ WARNING:

Do not excessively tighten Allen bolts. Doing so will result in damage to the adjuster and base pan.

**HARLEY-DAVIDSON ROAD KING FRONT SOLO
SARGENT HD PREMIUM SEAT**

TOOLS REQUIRED:

3mm Allen wrench.

SEAT INSTALLATION:

1. Fit the seat to the bike.
NOTE: When installing the seat, push down on the nose, making sure to engage the metal tongue on the motorcycle tank into the seat's receiver slot **A**.
2. **Optional nose adjustment:** If necessary, adjust the tongue tension by loosening the two Allen bolts **B** and evenly sliding the adjuster **C** up or down to achieve the optimal fit.
3. Retighten the bolts. Do not over tighten as this can result in damage to seat.
4. Reinstall seat and recheck fitment. Repeat adjustments as necessary for a snug fit.
5. Install both rear fender nuts. **D**

OPTIONAL NOSE ADJUSTMENT:

ALTHOUGH PRE-SET AT THE FACTORY, SOME MOTORCYCLES MAY REQUIRE THE BELOW ADJUSTMENT FOR BEST NOSE FIT.

