

<b>BIG BIKE PARTS®</b>		<b>INSTALLATION INSTRUCTIONS</b>	
Copyright © 2020 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.		PART NO. HG18SBO	SADDLEBAG ORGANIZER
8/26/2020		FOR HONDA GOLDWING GL1800 2018-NEWER	
TOOLS NEEDED:	RUBBING ALCOHOL	LINT FREE RAG	
<p><b>NOTE: ALWAYS ALLOW 24 HOURS FOR TAPE ADHESIVE TO CURE BEFORE USING.</b></p> <p>PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.</p> <p><b>INSTALLATION</b></p> <ol style="list-style-type: none"> <li>1. STARTING ON THE LEFT SIDE, TEST FIT THE LEFT SADDLEBAG ORGANIZER IN THE LEFT SADDLEBAG LID NOTING THE AREA TO BE CLEANED.</li> <li>2. REMOVE THE ORGANIZER AND USE A LINT FREE RAG AND SOME RUBBING ALCOHOL TO CLEAN THE LEFT SADDLEBAG LID AREA WHERE THE LEFT SADDLEBAG ORGANIZER IS BEING INSTALLED, LET DRY COMPLETELY.</li> <li>3. LOOKING AT THE BOTTOM OF THE LEFT SADDLEBAG ORGANIZER, REMOVE THE CLEAR BACKING FROM THE HOOK AND LOOP.</li> <li>4. CAREFULLY SET THE LEFT SADDLEBAG ORGANIZER BACK INTO PLACE AND APPLY PRESSURE TO ALL OF THE AREAS WITH THE HOOK AND LOOP.</li> <li>5. REPEAT STEPS 1-4 ON THE RIGHT SIDE.</li> <li>6. LET THE BIKE SIT FOR AT LEAST 24 HOURS FOR TAPE ADHESIVE TO CURE.</li> <li>7. REMOVE BOTH SADDLEBAG ORGANIZERS BY SEPARATING THE HOOK AND LOOP.</li> <li>8. CHECK TO MAKE SURE THAT ALL OF THE PIECES OF HOOK TAPE HAVE ADHERED TO THE SADDLEBAG LID FULLY. APPLY PRESSURE TO ANY LOOSE AREAS.</li> <li>9. REATTACH BOTH SADDLEBAG ORGANIZERS.</li> </ol>			

<b>BIG BIKE PARTS®</b>		<b>INSTALLATION INSTRUCTIONS</b>	
Copyright © 2020 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.		PART NO. HG18SBO	SADDLEBAG ORGANIZER
8/26/2020		FOR HONDA GOLDWING GL1800 2018-NEWER	
TOOLS NEEDED:	RUBBING ALCOHOL	LINT FREE RAG	
<p><b>NOTE: ALWAYS ALLOW 24 HOURS FOR TAPE ADHESIVE TO CURE BEFORE USING.</b></p> <p>PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.</p> <p><b>INSTALLATION</b></p> <ol style="list-style-type: none"> <li>1. STARTING ON THE LEFT SIDE, TEST FIT THE LEFT SADDLEBAG ORGANIZER IN THE LEFT SADDLEBAG LID NOTING THE AREA TO BE CLEANED.</li> <li>2. REMOVE THE ORGANIZER AND USE A LINT FREE RAG AND SOME RUBBING ALCOHOL TO CLEAN THE LEFT SADDLEBAG LID AREA WHERE THE LEFT SADDLEBAG ORGANIZER IS BEING INSTALLED, LET DRY COMPLETELY.</li> <li>3. LOOKING AT THE BOTTOM OF THE LEFT SADDLEBAG ORGANIZER, REMOVE THE CLEAR BACKING FROM THE HOOK AND LOOP.</li> <li>4. CAREFULLY SET THE LEFT SADDLEBAG ORGANIZER BACK INTO PLACE AND APPLY PRESSURE TO ALL OF THE AREAS WITH THE HOOK AND LOOP.</li> <li>5. REPEAT STEPS 1-4 ON THE RIGHT SIDE.</li> <li>6. LET THE BIKE SIT FOR AT LEAST 24 HOURS FOR TAPE ADHESIVE TO CURE.</li> <li>7. REMOVE BOTH SADDLEBAG ORGANIZERS BY SEPARATING THE HOOK AND LOOP.</li> <li>8. CHECK TO MAKE SURE THAT ALL OF THE PIECES OF HOOK TAPE HAVE ADHERED TO THE SADDLEBAG LID FULLY. APPLY PRESSURE TO ANY LOOSE AREAS.</li> <li>9. REATTACH BOTH SADDLEBAG ORGANIZERS.</li> </ol>			