

<b>BIG BIKE PARTS<sup>®</sup></b>		<b>INSTALLATION INSTRUCTIONS</b>			
Copyright © 2022 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.		PART NO. H44-4BK, H44-4RED, H44-4ZRED, H44-4BLUE, H44-4ZBLUE			DASH POUCH
6/14/2021		FITMENT: POLARIS SLINGSHOT 2015-NEWER			
TOOLS NEEDED:	RUBBING ALCOHOL	CLEAN RAG			
<p><b>PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.</b>  <b>ESTIMATED INSTALLATION TIME: 5 TO 10 MIN.</b></p> <p><b>INSTALLATION:</b></p> <ol style="list-style-type: none"> <li>1. TEST FIT THE CENTER POUCH ON DASH BOARD NOTING THAT IT ALIGNS WITH THE EDGE NEAREST THE DRIVER AND CENTERED ON THE DASH BOARD.</li> <li>2. REMOVE THE POUCH AND USE A LINT FREE RAG AND SOME RUBBING ALCOHOL TO CLEAN THE DASH BOARD AREA WHERE THE DASH POUCH IS BEING INSTALLED, LET DRY COMPLETELY.</li> <li>3. LOOKING AT THE BOTTOM OF THE DASH POUCH, REMOVE THE BACKING FROM THE HOOK AND LOOP.</li> <li>4. CAREFULLY SET THE DASH POUCH BACK INTO PLACE AND APPLY PRESSURE TO ALL OF THE AREAS WITH THE HOOK AND LOOP.</li> <li>5. LET THE SLINGSHOT SIT FOR AT LEAST 24 HOURS FOR ADHESIVE TO CURE.</li> <li>6. REMOVE DASH POUCH BY SEPARATING HOOK AND LOOP.</li> <li>7. CHECK TO MAKE SURE THAT ALL OF THE PIECES OF HOOK TAPE HAVE ADHERED TO THE DASH BOARD FULLY. APPLY PRESSURE TO ANY LOOSE AREAS.</li> <li>8. REATTACH THE DASH POUCH.</li> </ol>					
<div style="border: 1px solid blue; padding: 5px; width: fit-content; margin: auto;"> <p style="text-align: center; margin: 0;"><b>NOTICE</b></p> <p style="font-size: x-small; margin: 0;">IGNORING THE CONTENTS OF THESE INSTRUCTIONS MAY AFFECT THE PRODUCT PERFORMANCE AND FUNCTIONALITY. NOT FOLLOWING THESE INSTRUCTION MAY CAUSE DAMAGE TO THE PRODUCT OR THE VEHICLE TO WHICH IT IS BEING ATTACHED.</p> </div>			<div style="border: 1px solid blue; padding: 5px; width: fit-content; margin: auto;"> <p style="text-align: center; margin: 0;"><b>NOTICE</b></p> <p style="font-size: x-small; margin: 0;">THIS IS AN ADHESIVE BACKED PRODUCT. CAUTION MUST BE TAKEN DURING INSTALLATION TO PROPERLY POSITION FOR ONE TIME PLACEMENT. REPEAT TRIALS WILL RESULT IN FAILURE OF THE ADHESIVE.</p> </div>		

<b>BIG BIKE PARTS<sup>®</sup></b>		<b>INSTALLATION INSTRUCTIONS</b>			
Copyright © 2022 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.		PART NO. H44-4BK, H44-4RED, H44-4ZRED, H44-4BLUE, H44-4ZBLUE			DASH POUCH
6/14/2021		FITMENT: POLARIS SLINGSHOT 2015-NEWER			
TOOLS NEEDED:	RUBBING ALCOHOL	CLEAN RAG			
<p><b>PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.</b>  <b>ESTIMATED INSTALLATION TIME: 5 TO 10 MIN.</b></p> <p><b>INSTALLATION:</b></p> <ol style="list-style-type: none"> <li>1. TEST FIT THE CENTER POUCH ON DASH BOARD NOTING THAT IT ALIGNS WITH THE EDGE NEAREST THE DRIVER AND CENTERED ON THE DASH BOARD.</li> <li>2. REMOVE THE POUCH AND USE A LINT FREE RAG AND SOME RUBBING ALCOHOL TO CLEAN THE DASH BOARD AREA WHERE THE DASH POUCH IS BEING INSTALLED, LET DRY COMPLETELY.</li> <li>3. LOOKING AT THE BOTTOM OF THE DASH POUCH, REMOVE THE BACKING FROM THE HOOK AND LOOP.</li> <li>4. CAREFULLY SET THE DASH POUCH BACK INTO PLACE AND APPLY PRESSURE TO ALL OF THE AREAS WITH THE HOOK AND LOOP.</li> <li>5. LET THE SLINGSHOT SIT FOR AT LEAST 24 HOURS FOR ADHESIVE TO CURE.</li> <li>6. REMOVE DASH POUCH BY SEPARATING HOOK AND LOOP.</li> <li>7. CHECK TO MAKE SURE THAT ALL OF THE PIECES OF HOOK TAPE HAVE ADHERED TO THE DASH BOARD FULLY. APPLY PRESSURE TO ANY LOOSE AREAS.</li> <li>8. REATTACH THE DASH POUCH.</li> </ol>					
<div style="border: 1px solid blue; padding: 5px; width: fit-content; margin: auto;"> <p style="text-align: center; margin: 0;"><b>NOTICE</b></p> <p style="font-size: x-small; margin: 0;">IGNORING THE CONTENTS OF THESE INSTRUCTIONS MAY AFFECT THE PRODUCT PERFORMANCE AND FUNCTIONALITY. NOT FOLLOWING THESE INSTRUCTION MAY CAUSE DAMAGE TO THE PRODUCT OR THE VEHICLE TO WHICH IT IS BEING ATTACHED.</p> </div>			<div style="border: 1px solid blue; padding: 5px; width: fit-content; margin: auto;"> <p style="text-align: center; margin: 0;"><b>NOTICE</b></p> <p style="font-size: x-small; margin: 0;">THIS IS AN ADHESIVE BACKED PRODUCT. CAUTION MUST BE TAKEN DURING INSTALLATION TO PROPERLY POSITION FOR ONE TIME PLACEMENT. REPEAT TRIALS WILL RESULT IN FAILURE OF THE ADHESIVE.</p> </div>		