



*"Setting the World's
Performance Standards!"*

**Starting Line
Products, Inc.**

743 Iona Rd. Idaho Falls, ID 83401, (208)529-0244 Fax (208)529-9000

SLP Powder Snow Pre-Filter for 2008 Polaris 700-800 IQ Chassis Part #14-229

Kit Contents:

- (2) Pre-Filter Vents
- (14) 3/16" Plastic Rivets (#14-223)

1. Remove stock intake foam. Also remove plenum to prevent debris getting into the intake tract.
2. Center SLP Powder Snow-Pre Filter over intake hole. Using the Pre-Filter as a guide, drill 3/16" hole and fasten into place with plastic rivets provided.
3. Reassemble plenum. NOTE: make sure inside of plenum is clear of any debris that could be ingested into the engine.

