



*"Setting the World's
Performance Standards!"*

743 E. Iona Rd. Idaho Falls, ID 83401, (208)529-0244 Fax (208)529-9000

SLP High Flow Intake™

**for 2010-14 600 Rush, 2012-14 600 Switchback,
2014-16 Switchback Assault, 2012-16 600 RMK,
2012-15 600 Pro-RMK, 2013-16 600 Indy, 2011-14
800 Rush, 2012-14 800 Switchback, 2011-16 800
Switchback Assault, 2011-15 800 RMK Assault,
2011-16 800 RMK, 2011-15 800 Pro-RMK,
2014-16 800 Indy
Part #14-307**

Kit Contents:

- 4 - Push Darts (Part #14-249)
- 1 - 33" Foam Seal (Part #999-0148)
- 1 - Intake (Part #14-307-1)

Installation Instructions:

1. Remove hood from sled.
2. Place SLP Intake onto the console behind the gauge and mark around the outside with a marker.
3. Cut out the provided template using it as a guide to mark out the 7 holes to be drilled. **Note:** The center corners of the template need to align with raised area behind the gauge (see Illustration).
4. Using a 1 3/4" hole saw carefully cut out the 7 holes, **cutting through only the top of the air horns** on the inside. Use a Razor knife to trim the remaining corners of the air horns.

NOTE: Drill slowly and carefully.

5. Using SLP Intake as a guide, drill holes in the 4 corners using a **5/32” drill bit**.
6. Debur and vacuum out all plastic shavings. Failure to do so can cause severe engine damage.
7. Install foam seal to the bottom edge of the intake. Install intake using supplied push darts.
8. Reinstall hood onto the sled.

Illustration



