



Setting the World's  
Performance Standards

---

# SLP Cold Air Kit

## for Polaris 600 RMK/Switchback IQ Chassis

### Left Hand Side Part # 32-534

---

**Kit Contents:**

5 - Push Darts

4 - Rivet Washers

1 - Inlet Screen

4 - 3/16" Stainless Rivets

1 - Inlet Grate

1 - Outlet Grate

---

1. Remove left hand side panel.
2. Cut out template #1 and align with the back of the side panel (see illustration #1). Using a marker trace around the inside of the template. Remove template and cut with a rotary tool and a multi-purpose cutting bit. Debur the hole.
3. Using the outlet grate as a guide align with the areas cut out in step 2 and drill with an 11/64" drill bit. Start at the top and drill one hole at the top and drill one hole at a time and install with the supplied push darts and work your way down the grate.
4. Cut out template #2 and tape it to the outside of the belly pan on the back side of the shock tower (see illustration #2) Mark the inside of the template and cut out using a rotary tool and a multi-purpose cutting bit. Debur the holes.
5. Align the inlet grate with the areas cut out in step 4. Using the grate as a guide drill the 4 holes around the outer edge with a 3/16" drill bit.
6. Center the screen onto the inside of the belly pan over the six previously drilled holes and drill through the screen.
7. Place the grate on the outside of the belly pan and the screen on the inside and rivet into place using the 3/16" rivets and rivet washers provided.

## Illustration #1



## Illustration #2



# Template

