



*"Setting the World's  
Performance Standards!"*

---

743 Iona Rd. Idaho Falls, ID 83401, (208)529-0244 Fax (208)529-9000

## **SLP Control Hooks**

1. Remove old grips.

Option A: Blow off grips using compressed air.

Option B: Cut off old grips using a razor knife being careful not to cut the hand warmer tape

2. Slide Control Hooks into the ends of the handlebar. Torque bolt in the end of the hook to 18ft.lbs for a secure fit. (Bars can be shortened depending on personal preference for maximum control and comfort.)
3. Cut SLP Comfort Grips to desired length using a razor knife (SLP recommends 7"). Compressed air is the easiest method of installation. Loctite Super Glue is recommended as an adhesive. Drip the super glue into the open end of the grip and rotate to get glue to the bottom end of the grip and around the inside. Install the grip while the glue is still wet.

### **-WARNING-**

If grip begins to turn or move you must remove and reapply the grip as described in step 3 above. Failure to install the product as instructed may result in serious injury or death.