



*"Setting the World's
Performance Standards!"*

743 E. Iona Rd. Idaho Falls, ID 83401, (208)529-0244 Fax (208)529-9000

SLP Micro Tack™

Installation Instructions:

1) Remove old grips.

Option A: Blow off grips using compressed air.

Option B: Cut off old grips using a razor knife being careful not to cut the hand warmer tape.

2) Cut SLP Micro Tack™ to desired length using a razor knife. Compressed air is the easiest method of installation. If SLP Handlebar Hooks™, or BJ Hookers Handlebar Hooks are not used, Grips must be glued. SLP recommends using LOCTITE™ Brand "Quick Tite" super glue for best results. Apply a small, even amount of super glue on the bar and inside the grip. Slide the grip onto the bar and allow 5-10 minutes to dry.

-WARNING-

If grip begins to turn or move you must remove and reapply the grip as described in step 2 above. Failure to install the product as instructed may result in serious injury or death.