


INSTALLATION INSTRUCTIONS

Lift Kit: for Can-Am Commander

Do not discard packaging until product has been successfully installed.

Item	Description
A	Bracket, Passenger
B	Bracket, Driver
C	Rear Shock Bracket x 2



Liability Statement

SuperATV's® products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV® and is not recommended. SuperATV's® products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV® to verify that they will work together.

Although SuperATV® has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV® urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV® products, user agrees that should damages occur, SuperATV® will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV®, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV®. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV® will warranty only parts provided by SuperATV®. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV®. SuperATV® parts and products are not warranted if item was not installed properly, misused, or modified.

Installing, adding, modifying, or fabricating any factory or aftermarket product to your ATV/UTV may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of certain products on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of the product. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, traffic laws, and ordinances. It is your responsibility to know the laws and how they apply to you.

The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agrees to hold SuperATV® harmless from any damage resulting from failure to adhere to such specifications, warnings and/ or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws and ordinances when operating his/her vehicle while using this product, and the Buyer agrees to hold SuperATV® harmless from any violation thereof.

Need help with your installation?



sales@superatv.com



www.superatv.com



1-855-743-3427



8:00am - 8:00pm EST M-Th
8:00am - 7:00pm EST Friday
9:00am - 2:00pm EST Saturday

Read instructions and view illustrations before beginning.

Thank You

For Choosing



IMPORTANT: For Commander X Models:

- Disconnect Front Sway Bar from Lower A-Arms before beginning installation.
- Reconnect when installation is complete and machine is on ground.

- *Keep all components removed from machine.*
- *Do not tighten hardware completely unless noted.*






Front:

- Raise front off ground; secure with jack stands.
- Remove Wheels.
- Remove Shocks from Shock Mounts.
- Disconnect Air Hose as shown.




Front continued:

- Install and secure Bracket, Passenger (A) to Shock Mount with hardware shown.
- Repeat for opposite side.



Front continued: *do not tighten hardware completely unless noted.*

- Install Shocks to Brackets with hardware shown.




- Tighten all hardware completely. Reinstall Wheels.

Rear:

- Raise Cargo Box and remove Bed Stops.
- Raise rear off ground; secure with jack stands.
- Remove Wheels.
- Remove Shocks from Shock Mounts.




- Install Clip Nuts into stock Shock Mounts.




Rear continued: do not tighten hardware completely unless noted.

- Install Rear Shock Brackets (C) to stock Shock Mounts with hardware shown.




- Install Shocks to Rear Shock Brackets (C) with hardware shown.
- Reinstall Bed Stops.




- 2014+ years will require Differential Vent Tube rerouting. Reroute and secure to Rear Bracket (C). See following page.
- Tighten all hardware completely. Reinstall Wheels.

2014+ Differential Vent Tube rerouting:



**Rear Bracket contains mounting location for stock Vent Tube Mounting.
2014+ years will need to reroute and connect.**



2017+ Shock note:

