

## ATV/UTV TIE DOWN STRAP KIT

1. Install the deck hook into trailer or truck bed by drilling a 1/2" hole in the appropriate location beside each tire. Use the supplied nut and washer to tighten deck hook in place. It is best to install the deck hook through the frame of the trailer; if this cannot be done, use a backing support.
2. Loop the lasso end of the strap over the tire at the 10-2 position. Position the deck hook slightly towards the rear for the back tires and slightly towards the front for the front tires. See diagram.
3. Lock the adjustable anchor end into the supplied deck hook.
4. Look at the wheel as if you were looking at a clock and the anchor point would be 7:00 for the rear tires and 5:00 for the front, that will always put the lasso in the right position.
5. Tighten the lasso by pulling the end of the strap until the lasso and ratchet mechanism look like the picture below.
6. Then tighten the lasso by using the ratchet lever, tighten until strap depresses into tire approx. 1 inch.
7. Make sure the D ring is centered as close as possible, this may take loosening the strap a couple times and adjusting.
8. Once its centered and the strap is tightened, tie the remaining strap ends in such a way that is not able to flap in the wind. This can damage the finish on the wheel and or the deck

